



Inventory number: 22298

Band saw

KASTO SSB 260 VA

2000



### Technical data

|                         |           |
|-------------------------|-----------|
| Cut range: round up to  | 260 mm    |
| Square                  | 260 mm    |
| diameter min.           | 10 mm     |
| Smallest cutting length | 5 mm      |
| Outstanding length min. | 10 mm     |
| vertical                |           |
| hydraulic               |           |
| Automatic               |           |
| Cut length:             |           |
| min.                    | 5 mm      |
| max                     | 600 mm    |
| Max. automatic forward  |           |
| feed length             | 600 mm    |
| stepless                |           |
| from                    | 15 m/min  |
| up to                   | 125 m/min |
| Band length             | 4115 mm   |
| Band width              | 41 mm     |
| Sheet thickness         | 1.3 mm    |
| Voltage 50 Hz 3x        | 380 Volt  |
| Saw motor driving power | 4 kW      |

|                             |         |
|-----------------------------|---------|
| Power                       | 8 kW    |
| Machine's weight about      | 2200 kg |
| Overall dimensions machine: |         |
| Length                      | 2400 mm |
| Width                       | 1600 mm |
| Height                      | 2500 mm |
| Various accessories:        |         |
| Automatic forward feed      |         |
| Material bearing length     | 1 m     |
| Roller conveyor             |         |
| Coolant system              |         |
| Chip conveyor               |         |











**REIMMANN**

WERKZEUGMASCHINEN  
MACHINES-OUTILS

HCH. REIMMANN AG  
METTENBACHSTRASSE 27  
CH-8617 MÖNCHALDORF  
TEL. +41 (0)1 948 11 11  
FAX +41 (0)1 948 02 22

The control panel features a central LCD screen displaying a factory interior. To the right of the screen is a numeric keypad with buttons for digits 0-9, a red 'STOP' button, and a yellow 'START' button. Below the screen are four white rectangular buttons. The 'KASTO' logo is positioned to the right of these buttons. The main control area consists of a grid of 24 buttons: the first two columns have green buttons, the next two have red buttons, and the last two have blue buttons. The remaining 18 buttons in the grid are white.

STANGENMAGAZIN  
TAKTEN EIN AUS EIN

Physical controls include a black rotary knob, a green push-button, a black rotary knob, a black push-button, and a large yellow emergency stop button with a red top section.









